







FOR NOTES

VOLUME

FILTER

DIST.

		
VOLUME	FILTER	DIST.

 VOLUME	 FILTER	 DIST.
---	---	--

YERASOV MUSIC CORPORATION
www.yerasov.ru e-mail: sale@yerasov.ru

PACKAGE CONTENTS

1 Guitar pedal RT-10, pcs.....

1 User Manual, pcs.....

DISTORTION

RT-10

Guitar pedal



User manual

YERASOV.®

SAFETY MEASURES

- Keep away from high humidity.
- After exposure to cold, keep the device at room temperature for at least 30 minutes before switching on.
- Avoid dropping, keep away from dirt and water.

OVERVIEW

RT-10 is a distortion effect inspired by famous RAT* pedals. Almost clean slightly broken up sound, screaming overdrive or powerful distortion – you can get all these sounds from RT-10 by tweaking the knobs. We've used top notch state-of-the-art electronic components like noiseless microchips, high precision resistors and film capacitors. High quality footswitch made by ALPHA provides true bypass operation.


Built with the best available components on the market (WIMA film capacitors, low-noise chips, precision resistors, electrolytic capacitors with low leakage currents and a 2DPDT Alpha footswitch)

** All third party companies and products listed or otherwise mentioned in this document are trademarks of their respective owners and are in no way affiliated or associated with Yerasov Music Corporation. Product names are used solely to identify certain products whose tones and sounds were studied during model development for this product. The use of these names does not imply any cooperation or endorsement.*


APPLICATION

The pedal is powered by either a 6F-22 battery or a 9V DC adapter. We recommend using YERASOV AD9-100 or AD9-400 adapters. For extended battery life unplug the guitar cable when device is not being used.

- Install battery or plug the adapter in.
- Connect the pedal as shown in the illustration.
- Turn the guitar volume knob to the maximum level for best results.
- The LED light indicates that the pedal is turned on.
- The pedal provides linear frequency response with VOLUME and FILTER set to 12 o'clock and DIST set to minimum. Now turning FILTER knob clockwise will gradually cut the treble.
- Power up the pedal and turn on your amplifier.
- Once the effect is engaged, the red LED lights up.
- Set your instrument's volume to its maximum position and use LEVEL knob to eliminate volume difference when the effect is engaged. Finally, tweak other knobs to find the desired tone.




PANEL DESCRIPTION



- 1 - Output Jack
- 2 - **VOLUME** - volume control
- 3 - DC adapter input
- 4 - On / Off LED indicator
- 5 - **FILTER** - tone control
- 6 - **DIST.** - the amount of gain control
- 7 - Input Jack
- 8 - On / Off Switch

CONNECTION POLARITY OF DC ADAPTER



SCS PEDAL BOARD

YERASOV RT-10 is compatible with SCS Pedal Board. The SCS connector is at the bottom of the pedal, the cable is included in the SCS Pedal Board package. For more information please visit www.yerasov.ru

BATTERY REPLACEMENT

Access the battery compartment by unscrewing the bottom cover. Always put the cover back after replacing the battery.

SPECIFICATIONS

Input impedance, MOhm.....	1
Power supply (battery / DC), V.....	9
Current Draw, mA.....	7
Dimensions, mm.....	112 x 62 x 50
Weight, kg.....	0,25