




FOR NOTES



LEVEL TONE ATTACK SUSTAIN



LEVEL TONE ATTACK SUSTAIN



LEVEL TONE ATTACK SUSTAIN

YERASOV MUSIC CORPORATION
www.yerasov.ru e-mail: sale@yerasov.ru

COMPRESSOR BF-10

Guitar pedal



User manual

YERASOV.

- 1
- 1

SAFETY MEASURES

- Keep away from high humidity.
- After exposure to cold, keep the device at room temperature for at least 30 minutes before switching on.
- Avoid dropping, keep away from dirt and water.

OVERVIEW

BF-10 is a modern compressor-sustainer effect with four adjustable controls (**SUSTAIN**, **ATTACK**, **TONE** and **LEVEL**) and a true bypass mode.

Built with the best available components on the market (including a 2181 VC amplifier by THAT Corporation) BF-10 offers low noise, wide dynamic range, durability and flawless tone.

APPLICATION


The pedal is powered by either a 6F-22 battery or a 9V DC adapter. We recommend using YERASOV AD9-100 or AD9-400 adapters. For extended battery life unplug the guitar cable when device is not being used.

1. Install battery or plug the adapter in.
2. Connect the pedal as shown in the illustration.
3. Turn the guitar volume knob to the maximum level for best results.


4. The LED light indicates that the pedal is turned on

CONTROLS:
The **LEVEL** control balances out the clean / effect signal difference,

SUSTAIN sets the level of compression,
ATTACK emphasizes the nuances of picking technique
TONE adjusts the details of the sound.




PANEL DESCRIPTION



- 1 - Output Jack
- 2 - **LEVEL**- output level control
- 3 - **TONE**- tone control
- 4 - DC adapter input
- 5 - On / Off LED indicator
- 6 - **ATTACK**- attack level control
- 7 - **SUSTAIN** - sustain level control
- 8 - Input Jack
- 9 - On / Off switch

CONNECTION POLARITY OF DC ADAPTER



SCS PEDAL BOARD

YERASOV **BF-10** is compatible with SCS Pedal Board. The SCS connector is at the bottom of the pedal, the cable is included in the SCS Pedal Board package. For more information please visit www.yerasov.ru

BATTERY REPLACEMENT

Access the battery compartment by unscrewing the bottom cover. Always put the cover back after replacing the battery.

SPECIFICATIONS

Power supply (battery / DC), V.....	9
Current Draw, mA.....	15
Dimensions, mm.....	112 x 62 x 50
Weight, kg.....	0,25