
YERASOV. YERASOV.

FOR NOTES

STNATION ASAMONG	PACKAGE CONTEN
------------------	----------------

ser Manual, pcs1	
uitar pedal BC-10 , pcs1	e

9 S





YERASOV. YERASOV.


SAFETY MEASURES

- · Keep away from high humidity.
- After exposure to cold, keep the device at room temperature for at least 30 minutes before switching on.
 - Avoid dropping, keep away from dirt and water.

OVERVIEW

BC-10 is a modern distortion effect with a 3-band EQ. Built with the best available components on the market (film capacitors, precision resistors, electrolytic capacitors with low leakage currents) BC-10 offers durability and flawless tone.

PANEL DESCRIPTION



- 1 Output Jack
- 2 BASS low frequency control
- 3 VOLUME volume control
- 4 DC adapter input
- 5 On / Off LED indicator
- 6 MIDDLE middle frequency control
- 7 GAIN distortion level control
- 8 TREBLE high frequency control
- 9 Input Jack
- 10 On / Off switch

CONNECTION POLARITY OF DC ADAPTER



1

YERASOV.

APPLICATION

The pedal is powered by either a 6F-22 battery or a 9V DC adapter. We recommend using YERASOV AD9-100 or AD9-400 adapters. For extended battery life unplug the guitar cable when device is not being used.

- 1. Install battery or plug the adapter in.
- 2. Connect the pedal as shown in the illustration.
- 3. Turn the guitar volume knob to the maximum level for best results.
- 4. The LED light indicates that the pedal is turned on.

YERASOV.

2

SCS PEDAL BOARD


YERASOV **BC-10** is compatible with SCS Pedal Board. The SCS connector is at the bottom of the pedal, the cable is included in the SCS Pedal Board package. Fore more information please visit www.yerasov.ru

BATTERY REPLACEMENT

Access the battery compartment by unscrewing the bottom cover. Always put the cover back after replacing the battery.

SPECIFICATIONS

Power supply (battery / DC), V	9
Current Draw, mA	
Dimensions, mm	112 x 62 x 50
Weight, kg	



3